

Installation Instructions:

1. Remove the two torx screws below the instrument cluster
2. Open the glove box and remove the two torx screws that you exposed under the door. You may want to remove the entire door for ease of installation.



3. Slide the Dash cover into place installing one torx screw at a time starting right to left. For a tight fit the grommets are spread apart further than the actual holes in your Ranger. Pull the backing off the Velcro and stick.



4. Curve the plastic on the corner to fit behind the cup holder and slide up into place.



5. Install the torx screws you removed below the instrument cluster through the grommets on the cover.
6. Clean all areas of the dash with a degreaser (Simple Green, Rubbing Alcohol or equal) where the Velcro will be adhered to the plastic. It is critical that you do this at 65 degrees or warmer for the Velcro to stick.

Installation Instructions:

7. Peel back the backing on the Velcro and pull down on the cover like it will lie on the lower plastic and push to adhere.



8. Once the cover is tight, fold the bottom under and start drilling one hole at a time for the push darts using a 1/4 drill bit. Be sure to install the dart after you drill the hole. Repeat this for all 7 holes.



9. The left cover installs the same as the larger cover.



To make these compartments a little more water tight you can plug the drain holes inside each compartment at the bottom.

If you have any questions please call us @ 586-215-6849 Thank you for buying a REC-365 Product!